



MIRKA

The Pad Saver Strip enables smooth and stable net sanding. The pad saver strip prevents the backing pad from rapid wear out.

We recommend replacing the pad saver strip when the grip attachment of the net sanding strip becomes weak.

Application instruction:

- Apply and press the strip firmly to the backing pad. Fasten the net sanding strip to the pad saver strip.
- Place the sander on the object to be sanded and then start the sanding machine.

Net Pad Saver Strip



Quality from start to finish

